



User's manual SWIZA Tetis Chrono


Congratulations!

Your SWIZA Tetis Chrono watch is equipped with a Swiss Made quartz movement. This movement has been meticulously designed and manufactured with the highest quality materials and components to protect it against shock, variations in temperature, water and dust.

To ensure that your watch operates with perfect precision, please carefully read and adhere to the instructions included here.


Description of the display and control buttons

Display elements



Setting the time

- *Pull out the crown to position III (the watch stops)
- Turn the crown until you reach the correct time 8:45
- *Push the crown back into position




Please note

*In order to set the time to the exact second, ① must be pulled out when the second hand is in position «60». Once the hour and minute hands have been set, ③ must be pushed back into position I at the exact second

Setting the date (quick mode)

- Pull out the crown to position II (the watch continues to run)
- Turn the crown anticlockwise until the correct date [] appears
- Push the crown back into position I




Please note

During the date changing phase between approx. 9 PM and 12 PM, the date must be set to the date of the following day.

Setting the date/time following a battery change

Example:
- Date/time on the watch: [] / 01:25 AM
- Present date/time: [] / 8:30 PM

- Pull out the crown to position II (the watch continues to run)
- Turn the crown until yesterday's date appears []
- *Pull out the crown to position III (the watch stops)
- Turn the crown until the correct date [] appears
- **Continue to turn the crown until the correct time 8:30 PM appears
- Push the crown back into position I



Please note


*To set your watch to the exact second, please refer to the chapter entitled «setting the time»
**Please observe the AM/PM clock rhythm

Chronograph: basic function

Start / Stop / Reset

Example:


- Start**
Press push-button A
- Stop**
to stop the timing, press push-button A once more and read the chronograph hands: 1h 20 min 38sec
- Zero positioning**
Press push-button B (the chronograph hands will be reset to their positions)



Chronograph: accumulated timing

Example:

- Start**
start timing
- Stop**
e.g. 15 min 5 sec following ①
- Restart**
timing is resumed
- ***Stop**
e.g. 5 min 12 sec following ③ = 20 min 17 sec
- Reset**
The chronograph hands are returned to their zero positions




Please note

*Following ④, the accumulation of the timing can be continued by pressing push-button A (Restart / Stop, Restart / Stop...)

Chronograph: intermediate or interval timing

Example:

- Start**
start timing
- Display interval**
e.g. 20 min 17 sec (timing continues in the background)
- ***Making up the measured time**
the chronograph hands are quickly advanced to the ongoing measured time
- Stop**
final time is displayed
- Reset**
the chronograph hands are returned to their zero position



Please note


*Following ③, further intervals or intermediates can be displayed by pressing push-button B (display interval / make up measured time...)

Adjusting the chronograph hands to zero positon


Example:

One or several chronograph hands are not in their correct zero positions and have to be adjusted (e.g. following a battery change)

- Pull out the crown to position III (all chronograph hands are in their correct or incorrect zero position)
- Keep push-buttons A and B depressed simultaneously for at least 2 seconds (the second counter hand rotates by 360° – corrective mode is activated)



Adjusting the second counter hand



Adjusting the next hand




Adjusting the hour counter hand (position 6h)



Adjusting the next hand



Adjusting the minute counter hand (position 9h)



- Returning the crown to position I
Termination of the chronograph hands adjustment (can be carried out at any time)

